

### **SPg7 GPRS start up instructions after extended period of under-use**

- Before switching the terminal on, ensure the battery is sufficiently charged (place the terminal on a charging dock or connect a power supply directly to the device). A red LED light should appear in the top right corner of the screen. Ensure the battery is charged for at least 1 hour before switching the terminal on. If no red LED is seen – please follow power cable to the power source – ensure the cable is connected and the socket outlet power is switched on.
- To switch the terminal on - press and hold the power button for about 4 seconds allocated above nr '3' on the keypad
- After few seconds the terminal should display the message – 'Connecting to GPRS network – press cancel to skip' – **DO NOT PRESS CANCEL** and allow the process to continue.